


COYOTE® Defender Bolt Mounting Hardware Kit

Supplement to COYOTE Defender Application Procedure SP2906-2. (Catalog No. 710012362)

Be sure to read and completely understand this procedure before applying product. Be sure to select the proper PREFORMED product before application.



1.00 Instructions

- **1.01** For frame mounting instructions refer to SP2906-2.
- 1.02 Determine location for upper hole and drill to accept 5/8" or 16 mm bolt. Drill hole and apply corrosion inhibitor per your standard company practices.
- **1.03** The lower bolt hole can be located using the COYOTE Defender Frame.

- 1.04 Install the first nut and lock washer loosely on the frame for both upper and lower bolts.
- 1.05 Mount the closure with COYOTE mounting brackets supplied with the Defender. Tighten the first nut.
- 1.06 Raise the frame and closure up against the Lattice Tower to apply the second nut with washers on upper and lower bolts.
- **1.07** Tighten to secure frame, then proceed with door installation.

SAFETY CONSIDERATIONS

This application procedure is not intended to supersede any company construction or safety standards. This procedure is offered only to illustrate safe application for the individual. **FAILURE TO FOLLOW THESE PROCEDURES MAY RESULT IN PERSONAL INJURY OR DEATH.**

This product may be removed and reinstalled during the initial installation if it is in good condition. After extended service life, it is recommended the product not be reused once removed from service.

Do not modify this product under any circumstances.

This product is intended for use by trained technicians only. This product should not be used by anyone who is not familiar with, and not trained to use it.

When working in the area of energized lines, extra care should be taken to prevent accidental electrical contact.

For proper performance and personal safety, be sure to select the proper size PREFORMED product before application.

PREFORMED products are precision devices. To insure proper performance, they should be stored in cartons under cover and handled carefully.



P.O. Box 91129, Cleveland, Ohio 44101 • 440.461.5200 • www.preformed.com • e-mail: inquiries@preformed.com